

<b>COMMUNICATIONS RESOURCE AVAILABILITY WORKSHEET</b>	Frequency Band	Description
	<b>2 Meters 144.0000-148.0000</b>	<b>WCF EOC Primary VHF Repeaters Systems</b>

Channel Configuration	Channel Name/Trunked Radio System Talkgroup	Eligible Users	RX Freq N or W	RX Tone/NAC	TX Freq N or W	Tx Tone/NAC	Mode A, D or M	Remarks
Repeater	WX4E	Amateur	146.7450N	CSQ	146.1450N	136.5	A	CHARLOTTE County EOC
Repeater	W4MIN	Amateur	147.0750N	CSQ	147.6750N	100	A	DESOTO County EOC
Repeater	N4EMH	Amateur	146.6250N	CSQ	147.0250N	127.3	A	HARDEE County EOC
Repeater	W4HEM	Amateur	145.3300N	CSQ	144.7300N	100	A	HIGHLANDS County EOC
Repeater	N4TP	Amateur	147.1050N	CSQ	147.7050N	146.2	A	HILLSBOROUGH EOC
Repeater	K4GG	Amateur	146.8200N	CSQ	146.2200N	100	A	MANATEE County EOC
Repeater	WA4GDN	Amateur	146.6700N	CSQ	146.0700N	146.2	A	PASCO County EOC
Lkd Rptr - PACS	W4ACS	Amateur	145.1700N	CSQ	144.5700N	156.7	A	<b><i>Pinellas County EOC</i></b>
Lkd Rptr WC4PEM	WC4PEM	Amateur	146.9850N	CSQ	146.3850N	127.3	A	POLK County EOC

The convention calls for frequency lists to show four digits after the decimal place, followed by either an “N” or a “W”, depending on whether the frequency is narrow or wide band. Mode refers to either “A” or “D” indicating analog or digital (e.g. Project 25) or “M” indicating mixed mode. All channels are shown as if programmed in a control station, mobile or portable radio. Repeater and base stations must be programmed with the Rx and Tx reversed.